

# Quickstart Guide xBLOCK

## **Prerequisites:**

- DATA PANEL xtremeBLOCK (DP-81000-1-200) module + accessories
- IFM control / display control
- CodeSYS with necessary packages
- DC 12V or 24 V supply


# CODESYS PREPARATION

## Prepare Codesys

Depending on the type of controller you are working with, the corresponding packages must be installed in Codesys.

**i** The packages for the respective controller are supplied or you can obtain them on the manufacturer's website or in the Codesys Shop. It may be necessary to create an account for the corresponding pages.

- Open Codesys
- In the taskbar at the top via "**Tools -> Package Manager...**" open the package manager
- Right click on "**Install...**" and install the corresponding package
- In the following example the integration of an ifm display control is described



- Double-click or "Open" to install the package (this may take a moment)
- If the installation was successful, a corresponding message appears

## CODESYS PREPARATION

### Install EDS device file

- Open the device repository via **"Tools -> Device Repository"** in the taskbar at the top.
- Via the button **"Install..."** a new device can be installed
- **Double click** on the desired file, alternatively select and **open** the **\*. eds file** manually .  
The device appears in the list of added devices



The link below for you to our latest \*. eds file:


<https://www.data-panel.eu/media/archive/DP-81000-1-200-EDS.zip>

The image shows two overlapping windows from the CODESYS software. The top window is the 'Device Repository' dialog, which displays a list of installed device descriptions. The 'Vendor' is set to 'Data Panel GmbH'. The list includes a folder 'Fieldbuses' containing 'CANopen' and 'Remote Device', with 'Remote Device' expanded to show 'xBLOCK1214-MIO'. The bottom window is a Windows File Explorer showing the contents of a folder named 'Neuer Ordner' on the Desktop. The file 'xBLOCK1214-MIO\_CANeds\_V2 (2).eds' is highlighted in yellow. The 'Dateiname:' field at the bottom of the File Explorer is empty, and the file type is set to 'All supported description files'.

## CODESYS PREPARATION

### Codesys project


- Open Codesys
- Create a new project via **File -> New project**
- Select the connected controller via the library and confirm with **OK**. This action may take some time.



### CAN communication

- Open the communication path and right click on "CAN -> Attach device".
- Select "ifm" under the manufacturer and append the "ifmCANbus"
- Close window

 The controller must be CANopen capable. A J 1939 module variant is currently in preparation.



## CODESYS PREPARATION

### CANopen Manager

- Right click on the just inserted "ifmCANbus -> Attach device".
- Change manufacturer filter to <all manufacturers>.
- Select the device via "CANopen -> CANopenManager -> CANopenManager" and attach it.

Gerät anhängen

Name:

Aktion:  Gerät anhängen  Gerät einfügen  Gerät einstecken  Gerät aktualisieren

Zeichenfolge für eine Volltextsuche:  Hersteller: <Alle Hersteller >

Name	Hersteller	Version	Beschreibung
Feldbusse			
CANopen			
CANopenManager			
CANopen_Manager	3S - Smart Software Solutions GmbH	3.5.16.0	CANopen Manager
CANopen_Manager_SIL2	3S - Smart Software Solutions GmbH	3.5.16.0	CANopen_Manager_SIL2
CANopen_Manager_SoftMotion	3S - Smart Software Solutions GmbH	3.5.16.0	CANopen Manager SoftMotion
Lokales Gerät			
J1939			

Nach Kategorien gruppieren  Alle Versionen anzeigen (nur für Experten)  Veraltete Versionen anzeigen

**Name:** CANopen\_Manager  
**Hersteller:** 3S - Smart Software Solutions GmbH  
**Kategorien:** CANopenManager  
**Version:** 3.5.16.0  
**Bestellnummer:**  
**Beschreibung:** CANopen Manager

**Anhängen des ausgewählten Geräts als letztes "Kind" von ifmCANbus**

(Sie können einen anderen Zielgerätknoten im Navigator auswählen, solange dieses Fenster geöffnet ist)



# CODESYS PREPARATION

## STEP 1

- Append a new device to the CANopen\_Manager (right click -> Append device)
- Select the correct module based on the \*. eds file and close it

## STEP 2

- Open the configuration of the new device and set the node ID.
- Then go online, no errors should appear in the Codesys, the **COM LED** on the module should flash at short intervals



## ADDRESS

- The module has preset the base node ID 48 (0x30)
- By means of Node-ID connectors an offset can be set at the module. These can be found as [accessories in the DP Shop](#).
- Alternatively, it is possible to set the node-ID via PDO configuration, [see manual p. 46 - 47](#).



Node ID	Offset	Jumper Wire	
		CFG (X12) PINS	
48	0	-	
49	1	2-3	
50	2	1-2	
51	3	3-4	
52	4	2-3-4	
53	5	1-2 & 3-4	
54	6	1-4	
55	7	2-3 & 1-4	
56	8	1-2 & 1-4	

## CONNECTION OVERVIEW

<b>X5</b> CAN_OUT			<b>X1</b> VBAT_OUT
<b>X4</b> CAN_IN			<b>X2</b> VBAT_IN
<b>X6</b> AI_1-2	<b>X7</b> AI_3-4	<b>X14</b> PWMI_H3_1-2	<b>X18</b> PWMI_H3_3-4
<b>X8</b> AI_5-6	<b>X9</b> AI_7-8	<b>X15</b> DO_H3_1-2	<b>X19</b> DO_H3_3-4
<b>X10</b> DI_1-2	<b>X11</b> DI_3-4	<b>X16</b> PWM_H7_3	<b>X20</b> PWM_H7_4
<b>X12</b> CFG	<b>X13</b> PWM_H7_5	<b>X17</b> PWM_H7_6	<b>X21</b> PWM_H7_1-2

**!** Attention, if the xtremeBlock is used in combination with the xtremeDB modules, CAN-L and CAN-H must be switched at the CAN IN port of the xtremeBlock.

**!** If there are no further nodes, it is necessary to terminate the CAN line with a [120 Ohm resistor](#) on port X5 CAN\_OUT.

PORT no.	PORT Designation	Function
X2	VBAT_IN	Connection 2x supply voltage outputs and GND
X1	VBAT_OUT	Loop-on 1x supply voltage output and GND
X4	CAN_IN	Connection CAN and sensor voltage
X5	CAN_OUT	Loop on CAN and sensor voltage incl. GND
X6	AI_1-2	2x analog input 0 ... 10V / 0 ... 20 mA, alternatively DI
X7	AI_3-4	2x analog input 0 ... 10V / 0 ... 20 mA, alternatively DI
X8	AI_5-6	2x analog input 0 ... 10V / 0 ... 20 mA, alternatively DI
X9	AI_7-8	2x analog input 0 ... 10V / 0 ... 20 mA, alternatively DI
X10	DI_1-2	1x digital input PNP/NPN, frequency measurement 1x digital input PNP, frequency measurement
X11	DI_3-4	2x digital input PNP, frequency measurement
X12	CFG	2x configuration input Node-ID
X13	PWM_H7_5	High-side PWM output with current diagnostics
X14	PWMI_H3_1-2	High-side PWM output with accurate current diagnostics
X15	DO_H3_1-2	Digital output with current diagnostics
X16	PWM_H7_3	High-side PWM output with current diagnostics
X17	PWM_H7_6	High-side PWM output with current diagnostics
X18	PWMI_H3_3-4	High-side PWM output with accurate current diagnostics
X19	DO_H3_3-4	Digital output with current diagnostics
X20	PWM_H7_4	High-side PWM output with current diagnostics
X21	PWM_H_1-2	High-side PWM output with current diagnostics

## DI / AI - PORT X6-X9

The module has 8 input pins that can be configured either as analog or digital input. To carry out the parameterization, the corresponding SDO of the individual pins must be configured.

Port / Pin Module	Codesys SDO	Index	Port /Pin	Codesys SDO	Index
X6_2	AI_1	2100	X8_2	AI_5	2104
X6_4	AI_2	2101	X8_4	AI_6	2105
X7_2	AI_3	2102	X9_2	AI_7	2106
X7_4	AI_4	2103	X9_4	AI_8	2107

SubIndex	Description
01	0 = Not used ; 1 = AI_VOLTAGE; 2 = AI_CURRENT; 3 = DI_PNP
32	SENSOR_SUPPLY
3D	FILTER_DEEP
3F	MIN_DEVIATION

- Via the **SubIndex 01** the type of input is configured
- The sensor supply voltage can be activated via **subindex 32**
- The filter of the input can be configured via the **SubIndex 3D**. The function is only active if the pin is configured as an analog input. With analog input values, the measurement can be distorted by smoking. With the filter, the average of the last n measurements is formed and passed on.
- The measuring tolerance can be set via the **SubIndex 3F**. This function also affects the analog inputs. The measuring tolerance is used to set the change from which a measured value is updated.  
 e.g. A voltage of 5 V is to be measured, the value fluctuates between 4.995 V and 5.005 V. This leads to a "noise" of the input value. If a deviation of 15 (mV) is set, the input will not change until it falls below or exceeds the measurement tolerance. The unit for voltage is given in mV and for current in  $\mu\text{A}$ .

## EXAMPLE X6\_1 = DI // X7\_1 = AI\_V // X7\_2 = AI\_A

To configure e.g. **pin X6\_1** as digital input, **pin X7\_1** as analog voltage input and **pin X7\_2** as analog current input the following SDO are necessary:

	39	16#1800:16#01	Set and enable COB-ID	16#00000180	32
	40	16#1801:16#01	Disable PDO	16#80000280	32
X6_1	41	16#2100:16#01	AI_1_IO_TYPE (0 = Not Used, 1 = AI_VOLTAGE, 2 = AI_CURRENT, 3 = DI_PNP )	16#1	32
	42	16#2100:16#32	SENSOR_SUPPLY	16#1	16
X7_1	43	16#2102:16#01	AI_3_IO_TYPE (0 = Not Used, 1 = AI_VOLTAGE, 2 = AI_CURRENT, 3 = DI_PNP )	16#1	32
	44	16#2102:16#32	SENSOR_SUPPLY	16#1	16
	45	16#2102:16#3D	FILTER_DEEP	16#8	32
	46	16#2100:16#3F	MIN_DEVIATION	16#5	16
X7_2	47	16#2103:16#01	AI_4_IO_TYPE (0 = Not Used, 1 = AI_VOLTAGE, 2 = AI_CURRENT, 3 = DI_PNP )	16#2	32
	48	16#2103:16#32	SENSOR_SUPPLY	16#1	16
	49	16#2103:16#3D	FILTER_DEEP	16#8	32
	50	16#2103:16#3F	MIN_DEVIATION	16#10	16

**!** Attention, the SDO pin configuration must be configured after the SDO "Disable PDO" (in this case SDO 1801), otherwise the module remains in the default configuration.

The variable **DIGITAL\_INPUT\_AI\_1\_AI\_8** activates the configured digital inputs of the module. In this case **bit 0** which stands for **X6\_1**.

		DIGITAL_INPUT_AI_1_AI_8	%IB0	USINT	1
		Bit0	%IX0.0	BOOL	TRUE
		Bit1	%IX0.1	BOOL	FALSE
		Bit2	%IX0.2	BOOL	FALSE
		Bit3	%IX0.3	BOOL	FALSE
		Bit4	%IX0.4	BOOL	FALSE
		Bit5	%IX0.5	BOOL	FALSE
		Bit6	%IX0.6	BOOL	FALSE
		Bit7	%IX0.7	BOOL	FALSE
		DIGITAL_INPUT_DI_P_1_4_PWMi_H3_1_4	%IB1	USINT	0
		DIGITAL_INPUT_PWM_H7_1_6_DO_H3_1_2	%IB2	USINT	0
		DIGITAL_INPUT_DO_H3_3_4	%IB3	USINT	0
		Analog_INPUT_AI_1	%IW2	INT	0
		Analog_INPUT_AI_2	%IW3	INT	59
		Analog_INPUT_AI_3	%IW4	INT	167

The variable **Analog\_INPUT\_AI\_3** activates the configured analog input. Which in this case applies to **pin X7\_1**.

**!** It is recommended to deactivate unused pins via the SDO configuration. This has a significant positive effect on the CAN bus load.

## DI - PORT X10-X11

The module has slots that can be configured for **digital inputs**. In addition, these can also be configured as **frequency or encoder inputs**. To carry out the parameterization, the corresponding SDO of the individual pins should be configured.

Port / Pin Module	Codesys SDO	Index	Port /Pin	Codesys SDO	Index
X10_2	DI_P_1	2108	X11_2	DI_P_3	210A
X10_4	DI_P_2	2109	X11_4	DI_P_4	210B

SubIndex	Description
01	0 = Not used ; 3 = DI_PNP; 4 = FI_PNP; 1A = ENC_PNP
32	SENSOR_SUPPLY
3B	TIMEOUT_TIME
3E	GATE_TIME
44	RESOLUTION



X9\_1 can additionally be configured as minus-switching NPN (digital or frequency) input



For the acquisition of encoder signals usually two inputs are necessary

- **SubIndex 01** is used to configure the type of input. FI stands for a frequency-dependent input
- The sensor supply voltage can be activated via **subindex 32**
- The smallest detectable pulse duration can be determined via the **SubIndex 3F**. Default is 100ms. If no pulse is received for 100 ms, the I\_DIRECTION bit = 0 This function applies to frequency and encoder inputs.
- The "gate time" can be set via the **SubIndex 3E**. This function concerns frequency measurement at digital inputs. The gate time is the period in which the pulses are counted. The values of the frequency and periodic time are determined via this procedure
- The resolution at the encoder input can be set via **subindex 44**. This function concerns the encoder input

## EXAMPLE X10\_2 NPN X10\_4 PNP

To configure e.g. **pin X10\_2** as digital input NPN and **pin X10\_4** as digital input PNP the following SDO are necessary:

	69	16#1802:16#01	Set and enable COB-ID	16#000003B0	32
	70	16#1803:16#01	Disable PDO	16#800004B0	32
X10_2	71	16#2108:16#01	DI_P_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 4 = FI_PNP, 5 = DI_NPN, D = FI_N...	16#5	32
	72	16#2108:16#32	SENSOR_SUPPLY	16#1	16
X10_4	73	16#2109:16#01	DI_P_2_IO_TYPE (0 = Not Used, 3 = DI_PNP, 4 = FI_PNP, 1A = ENC_PNP)	16#3	32
	74	16#2109:16#32	SENSOR_SUPPLY	16#1	16

 Attention, the SDO pin configuration must be configured mandatory after the SDO "Disable PDO" In this case SDO 1803, otherwise the module remains in the default configuration.

The variable **DIGITAL\_INPUT\_DI\_P\_1\_4\_PWMi\_H3\_1\_4 Bit0** activates the configured digital inputs of the module. In this case the **Bit0** stands for the configured pin **X10\_2 NPN** and the **Bit1** stands for the configured pin **X10\_4 PNP**

		DIGITAL_INPUT_DI_P_1_4_PWMi_H3_1_4	%IB1	USINT	3
X10_4	Bit0		%IX1.0	BOOL	TRUE
X10_2	Bit1		%IX1.1	BOOL	TRUE
X11_4	Bit2		%IX1.2	BOOL	FALSE
X11_2	Bit3		%IX1.3	BOOL	FALSE
	Bit4		%IX1.4	BOOL	FALSE
	Bit5		%IX1.5	BOOL	FALSE
	Bit6		%IX1.6	BOOL	FALSE
	Bit7		%IX1.7	BOOL	FALSE
		DIGITAL_INPUT_PWM_H7_1_6_DO_H3_1_2	%IB2	USINT	0

 X10\_4 was configured as NPN input, here the signal changes to FALSE if the connected sensor is attenuated

## PWM / DO (DI) - PORT X13 & X16+X17 & X20+X21

The module has **five PWM pins** that can optionally be used as **digital inputs**. Alternatively, these PWM pins can also be configured as **digital outputs** with 3 or 7 amps current carrying capacity.

Port / Pin Module	Codesys SDO	Index	Port /Pin	Codesys SDO	Index
X13_2 & 4 (mirrored)	ANALOG_OUTPUT_U16_PWM_H7_5	2114	X17_2 & 4 (mirrored)	ANALOG_OUTPUT_U16_PWM_H7_6	2115
X16_2 & 4 (mirrored)	ANALOG_OUTPUT_U16_PWM_H7_3	2112	X20_2 & 4 (mirrored)	ANALOG_OUTPUT_U16_PWM_H7_4	2113
X21_2	ANALOG_OUTPUT_U16_PWM_H7_1	2110	X21_4	ANALOG_OUTPUT_U16_PWM_H7_2	2111



There are two PWM outputs on port X20

SubIndex	Description
01	PWM_H7_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, B = PWMO_HS7, C = DO_HS7)
1E	O_DIGITAL
1F	O_DUTYCYCLE
32	SENSOR_SUPPLY
33	PWM_FREQUENCY
34	DITHER_FREQUENCY
35	DITHER_AMPLITUDE
39	MAX_CURRENT
3A	OVERCURRENT_TIME
3D	FILTER_DEEP
3F	MIN_DEVIATION
40	MIN_CURRENT
41	OPENCIRCUIT_DETECTION

## PWM / DO (DI) - PORT X13 & X16+X17 & X20+X21

- Via the **SubIndex 01** the type of input is configured. Via the abbreviation HS the maximum current can be defined
- The output can be switched on via **SubIndex 1E**, provided that the pin is configured as a digital output. Has no meaning for other configurations
- **SubIndex 1F** can be used to set the keying behavior of the output, provided it has been configured as a digital output. Has no meaning for other configurations
- The sensor supply voltage can be activated via **subindex 32**
- Via **SubIndex 33** the frequency of the PWM output can be set.
- The Dither\_Frequency can be set via **SubIndex 34**. This value is superimposed on the piston of a hydraulic valve in order to keep it always minimally in motion at standstill. Without this value, the valve moves to a specified position. Here, the sliding friction changes to static friction, and when the valve is "restarted", stick-and-slip behavior occurs because the static friction is greater than the sliding friction. This behavior can be influenced by a dither frequency.
- The dither amplitude can be set via **subindex 35**
- Via **SubIndex 39** the maximum current of the pin can be set
- The time after which the output switches off when an overcurrent is present can be set via the **SubIndex 3A**.
- The filter of the input can be configured via the **SubIndex 3D**. The function is only active if the pin is configured as an analog input. With analog values, the measurement can be distorted by noise. With the filter, the average of the last **n** measurements is formed and passed on
- The measuring tolerance can be set via the **SubIndex 3F**. This function also affects the analog inputs. The measuring tolerance is used to set the change from which a measured value is updated.  
e.g. A voltage of 5 V is to be measured, the value fluctuates between 4.995 V and 5.005 V. This leads to a "noise" of the input value. If a deviation of 15 (mV) is set, the input will not change until it falls below or exceeds the measurement tolerance. The unit for voltage is given in mV and for current in  $\mu\text{A}$ .
- The minimum current can be set via **subindex 40**. If less than the current stored here flows, a cable break is detected. Default 200 mA for H3 and 500 mA for H7
- The cable break detection can be activated or deactivated via the **SubIndex 41**. Additionally it can be configured whether the detection is only checked at boot time or cyclically during operation.

## EXAMPLE X13\_2 PWM / X16\_2 PWM / X\_21\_2 DO

To configure e.g. **pin X13\_2** as PWM 7A , **pin X16\_2** as PWM 3A and **pin X21\_2** as **digital output** the following SDO are necessary:

	15	16#1401:16#01	Set and enable COB-ID	16#00000330
	16	16#1402:16#01	Disable PDO	16#80000430
X21_2	17	16#2110:16#01	PWM_H7_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, B = P...	16#7
	18	16#2110:16#39	MAX_CURRENT	16#0
X16_2	19	16#2112:16#01	PWM_H7_3_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, B = P...	16#6
X13_2	20	16#2114:16#01	PWM_H7_5_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, B = P...	16#C

**!** Attention, the SDO pin configuration must be configured after the SDO "Disable PDO" In this case SDO 1402, otherwise the module remains in the default configuration.

The variable **DIGITAL\_OUTPUT\_PWM\_H3\_1\_4\_PWM\_H7\_1\_4 bit 4** activates the configured **pin X21\_2**. If this bit is set to "**True**", the output at **pin X21\_2** is switched on.

The variable **ANALOG\_OUTPUT\_U16\_PWM\_H7\_3** activates the configured pin **X16\_2**, e.g. if the value "**500**" is stored here, the output is switched with a frequency of **500 Hz**.

The variable **ANALOG\_OUTPUT\_U16\_PWM\_H7\_5** activates the configured pin **X13\_2**, e.g. if the value "**1000**" is stored here, the output is switched with a frequency of **1,000 Hz**.

Variable	Mapping	Channel	Address	Type	Current Value
		DIGITAL_OUTPUT_PWM_H3_1_4_PWM_H7_1_4	%QB0	USINT	16
		Bit0	%QX0.0	BOOL	FALSE
		Bit1	%QX0.1	BOOL	FALSE
		Bit2	%QX0.2	BOOL	FALSE
		Bit3	%QX0.3	BOOL	FALSE
X21_2		Bit4	%QX0.4	BOOL	TRUE
X21_4		Bit5	%QX0.5	BOOL	FALSE
X16_2		Bit6	%QX0.6	BOOL	FALSE
X20_2		Bit7	%QX0.7	BOOL	FALSE
		DIGITAL_OUTPUT_PWM_H7_5_6_DO_H3_1_4	%QB1	USINT	0
		Bit0	%QX1.0	BOOL	FALSE
		Bit1	%QX1.1	BOOL	FALSE
		Bit2	%QX1.2	BOOL	FALSE
		Bit3	%QX1.3	BOOL	FALSE
		Bit4	%QX1.4	BOOL	FALSE
		Bit5	%QX1.5	BOOL	FALSE
		Bit6	%QX1.6	BOOL	FALSE
		Bit7	%QX1.7	BOOL	FALSE
		ANALOG_OUTPUT_U16_PWM_H3_1	%QW1	INT	0
		ANALOG_OUTPUT_U16_PWM_H3_2	%QW2	INT	0
		ANALOG_OUTPUT_U16_PWM_H3_3	%QW3	INT	0
		ANALOG_OUTPUT_U16_PWM_H3_4	%QW4	INT	0
		ANALOG_OUTPUT_U16_PWM_H7_1	%QW5	INT	0
		ANALOG_OUTPUT_U16_PWM_H7_2	%QW6	INT	0
X16_2 & X16_4		ANALOG_OUTPUT_U16_PWM_H7_3	%QW7	INT	500
		ANALOG_OUTPUT_U16_PWM_H7_4	%QW8	INT	0
X13_2 & X13_4		ANALOG_OUTPUT_U16_PWM_H7_5	%QW9	INT	1000
		ANALOG_OUTPUT_U16_PWM_H7_6	%QW10	INT	0
		DIGITAL_INPUT_AI_1_AI_8	%IB0	USINT	0
		DIGITAL_INPUT_DI_P_1_4_PWM_H3_1_4	%IB1	USINT	0

## DO / PWM / (DI) - PORT X15 + X19

The module has **two PWM pins** that can optionally also be used as **digital outputs**. In addition, these pins can also be configured as **PWM outputs** with 3 amps or as **digital inputs**.

Port / Pin Module	Codesys SDO	Index	Port /Pin	Codesys SDO	Index
X15_2	DO_H3_1	2116	X19_2	DO_H3_3	2118
X15_4	DO_H3_2	2117	X19_4	DO_H3_4	2119

SubIndex	Description
01	PWM_H7_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 7 = DO_HS3)
1E	O_DIGITAL
32	SENSOR_SUPPLY
39	MAX_CURRENT
3A	OVERCURRENT_TIME
3D	FILTER_DEEP
3F	MIN_DEVIATION
40	MIN_CURRENT
41	OPENCIRCUIT_DETECTION

- Via the **SubIndex 01** the type of input is configured. Via the abbreviation HS the maximum current is specified
- The output can be switched on via **SubIndex 1E**, provided that the pin is configured as a digital output. Has no meaning for other configurations
- **SubIndex 1F** can be used to set the keying behavior of the output, provided it has been configured as a digital output. Has no meaning for other configurations
- The sensor supply voltage can be activated via **subindex 32**
- Via **SubIndex 33** the frequency of the PWM output can be set.
- Via **SubIndex 39** the maximum current of the pin can be set

## DO / PWM / (DI) - PORT X15 + X19

- The time after which the output switches off when an overcurrent is present can be set via **SubIndex 3A**.
- The filter of the input can be configured via the **SubIndex 3D**. The function is only active if the pin is configured as an analog input. With analog values, the measurement can be distorted by noise. With the filter, the average of the last X measurements is formed and passed on.
- The measuring tolerance can be set via the **SubIndex 3F**. This function also affects the analog inputs. The measuring tolerance is used to set the change from which a measured value is updated.  
e.g. A voltage of 5 V is to be measured, the value fluctuates between 4.995 V and 5.005 V. This leads to a "noise" of the input value. If a deviation of 15 (mV) is set, the input will not change until it falls below or exceeds the measurement tolerance. The unit for voltage is given in mV and for current in  $\mu\text{A}$ .
- The minimum current can be set via **subindex 40**. If less than the current stored here flows, a cable break is detected. Default 200 mA for H3 and 500 mA for H7.
- The cable break detection can be activated or deactivated via the **SubIndex 41**. In addition, it can be configured whether the detection is only checked at startup or cyclically during operation.

## EXAMPLE X15\_2 DO

To configure e.g. **pin X15\_2** as digital output with 3 A the following SDO are necessary:

2	16#1400:16#01	Disable PDO	15#80000230
X15_2	3	16#2116:16#01	DO_H3_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 7 = DO_HS3)
			16#7



Attention, the SDO pin configuration must be configured after the SDO "Disable PDO" In this case SDO 1400, otherwise the module remains in the default configuration.

The variable **DIGITAL\_OUTPUT\_PWM\_H7\_1\_6\_DO\_H3\_1\_4 bit 2** activates the configured **pin X15\_2**. If this bit is set to "True", the output at pin **X15\_2** is switched on.

Variable	Mapping	Channel	Address	Type	Current Value
		DIGITAL_OUTPUT_PWM_H3_1_4_PWM_H7_1_4	%QB0	USINT	0
		DIGITAL_OUTPUT_PWM_H7_5_6_DO_H3_1_4	%QB1	USINT	4
		Bit0	%QX1.0	BOOL	FALSE
		Bit1	%QX1.1	BOOL	FALSE
X15_2		Bit2	%QX1.2	BOOL	TRUE
X15_4		Bit3	%QX1.3	BOOL	FALSE
X19_2		Bit4	%QX1.4	BOOL	FALSE
X19_4		Bit5	%QX1.5	BOOL	FALSE
		Bit6	%QX1.6	BOOL	FALSE
		Bit7	%QX1.7	BOOL	FALSE

## DO / PWMI / (DI) - PORT X14 + X18

The module has **four PWM pins** that can optionally also be used as **digital inputs**. In addition, these PWM pins can also be configured as **digital outputs** with 3 or 7 amps.

Port / Pin Module	Codesys SDO	Index	Port /Pin	Codesys SDO	Index
X14_2	PWMI_H3_1	210C	X18_2	PWMI_H3_3	210E
X14_4	PWMI_H3_2	210D	X18_4	PWMI_H3_4	210F



CPWMO corresponds to PWMI

SubIndex	Description
01	PWMI_H3_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, A = CPWMO_HS3)
1E	O_DIGITAL
1F	O_DUTYCYCLE
20	O_HCURRENT
32	SENSOR_SUPPLY
33	PWM_FREQUENCY
34	DITHER_FREQUENCY
35	DITHER_AMPLITUDE
36	CURRENT_CONTROL_P
37	CURRENT_CONTROL_I
38	CURRENT_CONTROL_E
39	MAX_CURRENT
3A	OVERCURRENT_TIME
3D	FILTER_DEEP
3F	MIN_DEVIATION
40	MIN_CURRENT
41	OPENCIRCUIT_DETECTION

## DO / PWMi / (DI) - PORT X14 + X18

- Via the **SubIndex 01** the type of input is configured. Via the abbreviation HS the maximum current can be defined. CPWMO stands for PWMi
- The output can be switched on via **SubIndex 1E**, provided that the pin is configured as a digital output. Has no meaning for other configurations
- **SubIndex 1F** can be used to set the keying behavior of the output, provided it has been configured as a digital output. Has no meaning for other configurations
- Via **SubIndex 20** the maximum current for the PWMi can be set
- The sensor supply voltage can be activated via **subindex 32**
- Via **SubIndex 33** the frequency of the PWM output can be set.
- The Dither\_Frequency can be set via **SubIndex 34**.
- The dither amplitude can be set via **subindex 35**
- Via **subindex 36** the **proportional part** of the current controlled PWMi pin can be set
- Via **subindex 37** the **integral part** of the current controlled PWMi pin can be set
- Via **subindex 38** the **differential part** of the current controlled PWMi pin can be set
- Via **SubIndex 39** the maximum current of the pin can be set
- The time after which the output switches off when an overcurrent is present can be set via the **SubIndex 3A**.
- The filter of the input can be configured via the **SubIndex 3D**.
- The deviation can be set via the **SubIndex 3F**.
- The minimum current can be set via **subindex 40**. If less than the current stored here flows, a cable break is detected. Default 200 mA for H3 and 500 mA for H7
- Via **SubIndex 41** the cable break detection can be activated or deactivated. In addition, it can be configured whether the detection is only checked at startup or cyclically during operation.

## EXAMPLE X14\_2 PWMi & X14\_4 PWMi

To configure e.g. the two pins **X14\_2** & **X14\_4** as PWMi pin the following SDO are necessary:

SDO	IO#1#UU:10#U1	Set and enable UOB-U	IO#UUUUU:U3U
9	16#1401:16#01	Disable PDO	16#80000330
<b>X14_2</b>	16#210C:16#01	PWMI_H3_1_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, A = CPWMO_HS3)	16#A
<b>X14_4</b>	16#210D:16#01	PWMI_H3_2_IO_TYPE (0 = Not Used, 3 = DI_PNP, 5 = DI_NPN, 6 = PWMO_HS3, 7 = DO_HS3, A = CPWMO_HS3)	16#A
17	16#1601:16#00	Clear pin mapping	16#0



Attention, the SDO pin configuration must be configured after the SDO "Disable PDO" In this case SDO 1401, otherwise the module remains in the default configuration.

The variable **ANALOG\_OUTPUT\_U16\_PWMi\_H3\_1** takes care of the configured pin **X14\_2**. The variable **ANALOG\_OUTPUT\_U16\_PWMi\_H3\_2** takes care of the pin **X14\_4**

Variable	Mapping	Channel	Address	Type	Current Value	Pr
		DIGITAL_OUTPUT_PWMi_H3_1_4_PWM_H7_1_4	%QB0	USINT	0	
		DIGITAL_OUTPUT_PWM_H7_5_6_DO_H3_1_4	%QB1	USINT	0	
	X14_2	ANALOG_OUTPUT_U16_PWMi_H3_1	%QW1	INT	200	
	X14_4	ANALOG_OUTPUT_U16_PWMi_H3_2	%QW2	INT	200	
	X18_2	ANALOG_OUTPUT_U16_PWMi_H3_3	%QW3	INT	0	
	X18_4	ANALOG_OUTPUT_U16_PWMi_H3_4	%QW4	INT	200	
		ANALOG_OUTPUT_U16_PWM_H7_1	%QW5	INT	0	
		ANALOG_OUTPUT_U16_PWM_H7_2	%QW6	INT	0	
		ANALOG_OUTPUT_U16_PWM_H7_3	%QW7	INT	0	
		ANALOG OUTPUT U16 PWM H7 4	%QW8	INT	0	



## GENERAL DIAGNOSIS

The module brings a variety of general diagnostics that can be read back via the Emergency Messages reported back from the CANopen CIA405 specification. An overview of the individual messages is shown in the following table

Code	Description
0x0000	No error or error reset
0x1000	Generic error
0x2300	Total current is too high
0x3100	Voltage outside the required tolerance
0x4200	Device temperature too high
0x8110	CAN data overrun (objects lost)
0x8130	Life Guard Error or Heartbeat Error
0x8140	Recoverd from Bus-Off
0x8210	Processing error due to incorrect length of the PDOs
0x8220	PDO length exceeded
0xff00	Configuration error on the device
0xff01	IO pin Overvoltage
0xff02	IO pin overcurrent
0xff03	IO pin Supplyfault
0xff04	Reserved
0xff05	IO pin open load
0xff06	IO pin timeout
0xff07	IO pin CC_Unlock

## GENERAL DIAGNOSIS

The general diagnostics can be read out via the Emergency Messages. A standardized block of the CIA405 is used for this purpose. In this case the block CIA405.RECV\_EMCY

Input Assistant

Text Search Categories

cia405.re

2 item(s) found.

Name	Type
<b>CIA405.RECV_EMCY</b>	FUNCTION_BLOCK
<b>CIA405.RECV_EMCY_DEV</b>	FUNCTION_BLOCK

Filter: None

Insert with arguments  Insert with namespace prefix

Documentation

FUNCTION\_BLOCK RECV\_EMCY  
EXTENDS CIA405Base  
Function block checks if an emergency object has been received from any DEVICE.  
If the function block has finished its action without any error, output CONFIRM is changed to TRUE and ERROR to 0.

NETWORK (CIA405Base)	USINT	1	VAR_INPUT
ENABLE (CIA405Base)	BOOL	FALSE	VAR_INPUT
TIMEOUT (CIA405Base)	UDINT	0	VAR_INPUT
CONFIRM (CIA405Base)	BOOL	FALSE	VAR_OUTPUT
ERROR (CIA405Base)	CANOPEN_KERNEL_ERROR	CANOPEN_KERNEL_ERROR.CANOPEN_KERNEL_NO_ERROR	VAR_OUTPUT
DEVICE	DEVICE	0	VAR_OUTPUT
ERRORINFO	EMCY_ERROR		VAR_OUTPUT

OK Cancel

## GENERAL DIAGNOSIS

First it is necessary to declare the block:

```
VAR
  xEnable : BOOL; // Enables the block
  xEMCYPending : BOOL;
  EMCY : CIA405.EMCY_ERROR; //contains the CAN error information
  NodeID : CIA405.DEVICE; //Node ID of the CAN node
  RecvEMCY : CIA405.RECV_EMCY; // Returned error message
  EMCY_array_string : ARRAY[0..1000] OF STRING; //EMCY
  i : INT := 0; // Auxiliary variable for programming
```

END\_VAR

Afterwards a small logic application has to be programmed to read out the values

```
xEnable := TRUE; // Activates the block
IF RecvEMCY.CONFIRM = TRUE THEN // Error message is present
  IF RecvEMCY.DEVICE <> 0 THEN // Error message is present at device with NodeID
    xEMCYPending := TRUE; // An error message is present
    EMCY := RecvEMCY.ERRORINFO;
    NodeID := RecvEMCY.DEVICE;
    i :=i + 1;
  ELSE
    xEMCYPending := FALSE; // No error message is present
  END_IF
CASE EMCY.EMCY_ERROR_CODE OF // Assign the error message
  16#0000: EMCY_array_string[i] := '0x0000 : No Error or Error Reset (WR)';
  ...
  16#FF07: EMCY_array_string[i] := '0xff07 : IO port CC_UNLOCK';
END_CASE;
xEnable := FALSE; // Block is activated
ELSIF RecvEMCY.ERROR <> CIA405.CANOPEN_KERNEL_ERROR.CANOPEN_KERNEL_NO_ERROR THEN
  // an error occurred while processing RecvEMCY, e.g. an incorrect NodeID or NetworkID.
  xEnable := FALSE;
END_IF
RecvEMCY( ENABLE := xEnable,
  NETWORK := CANbus.NetId + 1, //CODESYS NetId starts with 0 (the number entered in the CANbus
  configurator); CiA405 NETWORK with 1; That is the reason why we have to increment it here.
  TIMEOUT := 0 // no timeout required for RecvEMCY because it is processed locally.
);
IF i >= 999 THEN // Utility program for incrementing
  i:=0;
END_IF;
```

## PORT-BASED DIAGNOSES

Additionally it is also possible to read out the status or e.g. current directly of a port. For this purpose, the data is read directly from an SDO. For this there is a standardized module of the **canOpen CIA405 specification (CAA CiA405 library)** additionally the read back value should be interpreted or converted. For this the Codesys library **MemoryUtils** is used. In the following example the current of a **PWMI port (X14 P4)** is read back.

The current values of each port are always returned in **subindex 13** in this case **index 210D subindex 13**. In a first step the necessary variables and blocks must be declared.

Name	Namespace	Effective version
3S CANopenStack = 3S CANopenStack, 3.5.15.0 (3S - Smart Software Solutions GmbH)	_3SCOS	3.5.15.0
3SLicense = 3SLicense, 3.5.16.0 (3S - Smart Software Solutions GmbH)	_3S_LICENSE	3.5.16.0
BreakpointLogging = Breakpoint Logging Functions, 3.5.5.0 (3S - Smart Software Solutions GmbH)	BPLog	3.5.5.0
CAA CIA405 = CAA CIA 405, 3.5.15.0 (CAA Technical Workgroup)	CIA405	3.5.15.0
CAA Device Diagnosis = CAA Device Diagnosis, 3.5.15.0 (CAA Technical Workgroup)	DED	3.5.15.0
CANbusDevice = CANbusDevice, 3.5.15.0 (3S - Smart Software Solutions GmbH)	CANbusDevice	3.5.15.0
CDS_MemMan = CoDeSys Memory Manager, 3.5.12.0 (3S - Smart Software Solutions GmbH)	CMM	3.5.12.0
ifm_ecomatDisplay_Cnt, * (ifm electronic)	ifm_ecomatDisplay_Cnt	1.0.0.0
IoStandard = IoStandard, 3.5.15.0 (System)	IoStandard	3.5.15.0
Memory, 3.5.7.0 (3S - Smart Software Solutions GmbH)	Memory	3.5.7.0
MemoryUtils, 3.5.15.0 (3S - Smart Software Solutions GmbH)	MEMUtils	3.5.15.0
Standard = Standard, 3.5.15.0 (System)	Standard	3.5.15.0
System_VisuElem3DPath = VisuElem3DPath, 3.5.16.0 (System)	VisuElem3DPath	3.5.16.0
System_VisuElemCamDisplayer = VisuElemCamDisplayer, 3.5.16.0 (System)	VisuElemCamDisplayer	3.5.16.0
System_VisuElemMeter = VisuElemMeter, 3.5.16.0 (System)	VisuElemMeter	3.5.16.0
System_VisuElems = VisuElems, 3.5.16.0 (System)	VisuElems	3.5.16.0

### PROGRAM Diagnosis

#### VAR

xEnable : BOOL; // This variable activates the block, which is automatically set to FALSE again after the value has been read out

dwValue : DWORD; //Read back value

dwAbortCode : DWORD; //Error value if reading is not possible

dwStatusValue : DWORD;

dwStatusAbortCode : DWORD;

SPWR\_1\_SDORead : CIA405.SDO\_READ4; //Block for reading the SDO

#### END\_VAR

## PORT-BASED DIAGNOSES

If the variable **xEnable** is set to "TRUE", the following program code is executed. Via the block **SPWR\_1\_SDOREAD** the SDO with the **index 210D subindex 13** is read. Then this value is "copied" and converted. Afterwards the result can be found in the variable **dwValue**.

```

IF SPWR_1_SDORead.CONFIRM THEN
    //Value read back without error, copy data from block
    MEMUtils.MemCpy(pbyDest := ADR(dwValue), pbySrc := ADR(SPWR_1_SDORead.DATA[1]), dwSize :=
SIZEOF(dwValue));
    //On big-endian systems: dwValue must be changed to CANopen byte order (= little endian).
    MEMUtils.SwapLocalToIntel(pAddress := ADR(dwValue), iSize := TO_INT(SIZEOF(dwValue)); //Function
swaps only on big-endian systems
    xEnable := FALSE;
ELSIF SPWR_1_SDORead.ERROR <> CiA405.CANOPEN_KERNEL_ERROR.CANOPEN_KERNEL_NO_ERROR THEN
    // Error during readout
    IF SPWR_1_SDORead.ERROR = CIA405.CANOPEN_KERNEL_ERROR.CANOPEN_KERNEL_OTHER_ERROR THEN
        MEMUtils.MemCpy(pbyDest := ADR(dwAbortCode), pbySrc := ADR(SPWR_1_SDORead.ERRORINFO), dwSize
:= SIZEOF(dwAbortCode));
        MEMUtils.SwapLocalToIntel(pAddress := ADR(dwAbortCode), iSize := TO_INT(SIZEOF(dwAbortCode));
    END_IF
    xEnable := FALSE;
END_IF
SPWR_1_SDORead(
    NETWORK:= CANbus.NetId + 1, //CODESYS NetId starts by 0 (the number entered into the CANbus
configurator); CiA405 NETWORK by 1; That is the reason why we have to increment it here.
    ENABLE:= xEnable,
    TIMEOUT:= 0, //Timeout for SDO read in ms. Here: 0 ==> no timeout
    DEVICE:= xBLOCK1214_MIO.NodeID, // NodeID of destination device
    CHANNEL:= 0, //SDO channel which should be used. 0 means auto channeling ==> the next free channel will
be used. It depends on the slave which settings are working here but 0 and channel 1 is always working.
    INDEX:= 16#210D, //Index to be read out
    SUBINDEX:= //subindex13 to be read out );

```

	ANALOG_OUTPUT_U16_PWMi_H3_1	%QW1	INT	0	
	ANALOG_OUTPUT_U16_PWMi_H3_2	%QW2	INT	1000	
	ANALOG_OUTPUT_U16_PWMi_H3_3	%QW3	INT	0	
	ANALOG_OUTPUT_U16_PWMi_H3_4	%QW4	INT	0	

Expression	Type	Value	Prepared value
xEnable	BOOL	FALSE	
dwValue	DWORD	999	
dwAbortCode	DWORD	0	
dwStatusValue	DWORD	0	
dwStatusAbortCode	DWORD	0	
SPWR_1_SDORead	CIA405.SDO_READ4		



Application solutions & products for simple, decentralized and high-quality machine installation

# Mobile automation plugged in - what else!